

Care and Maintenance

Wood

For general cleaning, washing with a soft cloth and solution of mild detergent and warm water. Rinse thoroughly and dry with a soft cloth. If the surfaces become stained, use a non-abrasive

To dust your wood furniture regularly to avoid build-up of dirt and grime that can dull the finish. Dust with a dap cloth following the grain of the wood.

Do not use excess amounts of water on the wood surface.

Do not use powdered abrasives or other harsh cleaners like hypochlorite bleach, hydrogen peroxide, nitric or hydrochloric acids, or lye; they may deface the surface and or. change the finish color.

Metal Components

Using the warm water and a mild detergent will remove most spills and scuffs.

Polyvinyl chloride (PVC)

To wash Polyvinyl chloride surface with a soft cloth soaked in mild detergent and warm water. Rinse thoroughly and dry with a soft cloth.

Do not use solvents or abrasive kitchen cleaners.

Fabric

For normal cleaning, vacuum upholstery fabric and panel cloth as needed, using an upholstery attachment. If further cleaning is needed, dry-clean or spot clean fabric with a solvent cleaner.

Do not brush fabric or use a vacuum attachment with a rotary brush.

Brushing may permanently damage the nap or change the character of the fabric.

Do not apply water or any liquid solution. Wetting the fabric with any liquid solution may result in permanent damage.

Polycarbonate

To rinse the surface with clean water to remove any particles of dust or other abrasive materials. Sponge the plastic gently with warm water and a mild, nonabrasive soap or solution of ammonia and water. Rinse thoroughly with clean water and dry with a soft cloth. After cleaning, the acrylic glazing can be polished with a good wax polish applied with a clean, soft flannel pad.